
PRACTICAL-4


Aim: Working with attributes, terrain Data.


Steps:

Step 1 – Open QGIS Desktop and create a new project. Layer > Add Layer > Add Vector Layer.





Step 2 – Select the following file and click add.







Step 3 – Right click on the layer and open Attribute Table.







Step 4 – Click the select features using expression tool and enter the following expression then click select features.









Step 5 – Create a new project and add the following raster layer.




Step 6 - Raster > Extraction > Clip Raster by Extent.




Step 7 – Set the following parameters and hit run.




Step 8 – Raster > Extraction > Contour.




Step 9 – Set the following parameters and hit run.







Step 10 – To find the highest point open the attribute table. Sort the elev column in descending order, select th first row and click the zoom map to selected rows tool.




The point with highest elevation is highlighted.




Step 11 - To get labels, open layer properties in that open the layer menu then select the following options and then hit apply.





Step 12 – Raster > Analysis > Hill Shade.



Step 13 – Set the following parameters and hit run.

